


SMART PROJECTOR

User Manual




Interface/Button Diagram



Note: Different models of product interfaces and buttons will be different, depending on the actual product.

Remote Control




First of all thank you for using our product! Please read this manual carefully before using so it will help you to quickly be familiar with this product.

In case of any printing or translation error, we apologize for the inconvenience. As for the content change, we are sorry for no further notice.

HD IN

- ① One end of the HD data line is connected to the HD-IN interface of the projector, and the other end is connected with the HD-OUT interface of computer/other devices.
- ② Enter the "HD IN" on the projector.




Power on/Power off

- ① Power on: Switch the **[ON/OFF]** of the projector to the "ON" state, and press the **[P]**, the indicator is blue, waiting for the screen to display.
- ② Power off: Press the **[P]**, the interface of shutdown will pop up, click "OK" to shut down, after the projector stops running, please switch the **[ON/OFF]** to the "OFF" state, otherwise the battery will still be in a power-consuming state.

Sharpness


Turn the focus gear of the projector to adjust the picture sharpness.

Settings



BT Setting



Enter "Settings" → "BT Setting", click the switch to the "ON" state, search for the device which you want to connect, pairing.



3

WI-FI Setting



Enter "Settings" → "Networking Setting" → "WI-FI Setting", click the switch to "ON" state, select the network which you want to connect, enter the password and click "Link".



4

Hotspot Setting

Enter "Settings" → "Networking Setting" → "Hotspot Setting", click the switch to "ON" state, you can set the parameters, click "OK", and then the projector's hotspot can be searched by other devices to share the network.



5

Wireless Display

First of all, devices and projectors need to be connected to the same network.

EShareServer (For iPhone/iPad/Windows/Android system): Enter the APP "EShareServer" on the projector and follow the steps of the screen.

(Note: In the absence of a network, the device can be connected to the hotspot of the projector.)



Miracast (For Android system) :

- ① Enter the APP "Miracast" on the projector.
- ② Enter "Wireless display" interface on Android devices, and then search the device name of projector for matching.

iMirror (For iOS system) :

- ① Enter the APP "iMirror" on the projector.
- ② Open the "Screen Mirroring" on the iPhone/iPad, and then search the device name of projector for matching.

(Note: In the absence of a network, the device can be connected to the hotspot of the projector.)

6


Language Setting

Enter "Settings" → "Language Setting" and select the language you want to switch.




APP Install/Uninstall

① APP Install: If the APK Downloaded, enter the "App Center" → "AppInstaller", find the location of the APK, click and install it; If the APK is not downloaded, you can download and install it in the "Google Play".



7

② APP Uninstall: Enter "Settings" → "Other Setting" → "Apps", click the App that needs to be uninstalled.



File Browser


- ① Read: Insert the U disk/TF card, enter the "File Browser".
- ② Edit: Select the menu icon , tick the file you want to operate , deselect the menu icon , select the options you want to operate in the edit icon directory .
- ③ If "Cut" or "Copy" is selected, you need to first select the directory, and then click the edit icon  to select "Paste".



8

Factory data reset

Enter "Settings" → "Other Setting" → "Backup & reset" → "Factory data reset" → "RESET MBX".



Notes

- Make sure to use a standard power adapter. Other adapters may cause serious damage to the projector.
- Please keep the lens clean, dirt or scratches will affect the projection effect.
- Before you clean the projector, disconnect the power supply, clean it with a clean cotton wool or soft cloth, and then wipe off the residual moisture with a dry cloth.
- Do not place or drop hard objects on the projector.
- Do not place the projector on your legs or any part of your body to prevent injury from the heat.
- Avoid using the projector during weather of high humidity or thunderstorms.

9