







Guangzhou puppy robotics Co.,Ltd

**A smarter life at your fingertips**

# Welcome to puppy cube!


## 🌟 Device

### 📺 Device Overview



- 1 Power button
- 2 Volume buttons
- 3 Microphone
- 4 Camera lens
- 5 Indicator
- 6 Projection window
- 7 Speaker
- 8 Back cover
- 9 Charging port
- 10 HDMI 2.0
- 11 RESET hole
- 12 USB 3.0
- 13 Headphone jack

### 🔌 Power-On/Power-Off/Screen-Off




- Power-On: When the device is off, press and hold the power button for 3 seconds to turn it on.
- Power-Off: When the device is on, press and hold the power button for 3 seconds and select Power Off in the shutdown menu that appears.
- Screen-Off: When the device is on, press the power button to turn off the screen display.

## Vertical/Horizontal

### 1. Vertical Touch Control Projection:


Stand the device upright on a flat surface. After turning it on, you can perform touch control operations in the projection area.



\* Do not place objects in the projection area and avoid strong light sources that shine on the projection area.

## 2. Horizontal Cinema Projection:

Lay the device horizontally on a flat surface. After turning it on, you can project a large cinema-style screen on a wall or projection screen. To enlarge or reduce the projection area, adjust the distance between the wall or screen and the device.



\* Do not place objects in the projection path or projection area and avoid strong light sources that shine on the projection area.

When the device is in the horizontal position, it is better to operate using the remote control.

## 🎯 Auto Focus

After the device turns on, it performs auto focus for about 4 seconds to adjust the picture clarity. To perform auto focus again, tilt the device forward about 30° and stand it up straight again.

## Device Indicator

Device State	Operation State	Indicator State
Charging	Charging	Orange light
	Fully charged	Green light (turns off after five minutes)
Low battery	Battery $\leq$ 15%	Red light
Power-Off	No external power supply/battery	No lights

## Wireless Projection


When the device is connected to the same WLAN as your mobile phone or tablet, enable the projection function on the phone or tablet and, in the device list that appears, select the option that includes the words "puppy cube" to connect.

## Hard Reset (Fault Recovery)

When the device crashes or does not work normally, press and hold the power button for 15 seconds to force restart the device.  
If the force restart operation has no effect, insert a pin or other long and thin object into the RESET hole to force shut down the device. After the device shuts down, press the power button to restart the device and complete the reset operation.

# Remote Control

## Remote Control Overview



- 1 On/Off button
- 2 Focus button
- 3 Directional and selection buttons (up, down, left, right, OK)
- 4 Back button
- 5 Home button
- 6 Menu button
- 7 Volume buttons (-, +)

## Remote Control Indicator

Remote Control State	Operation State	Indicator State
Pairing	Press and hold the Back and Menu buttons for 3 seconds	Blue and red lights flash alternatively for 60 seconds
Paired	Any button is pressed	Blue light flashes once
Charging	Charging	Red light remains on
	Fully charged	Green light remains on
Low battery	Any button is pressed	Red light flashes twice


## Enable Auto Focus

Press the "Focus" button on the remote control to enable the device's auto focus function.

## What's in the Box



Device



Remote control



Power cord



Power adapter



Data cable



Instruction manual



Warranty card

## Precautions

- Do not point the projector at eyes, as it may cause injury.
- Do not obstruct the air inlet/outlet. Otherwise, abnormal heat ventilation may cause damage to the device.
- Do not place the device in areas with excessively high or low temperatures. The temperature of the operating environment should be  $-10^{\circ}\text{C}$  to  $40^{\circ}\text{C}$ .
- Use the device in a clean and dry environment. Avoid exposure to liquid splashes and rain, as the device is not designed to be water-resistant.
- Do not rinse the device using chemicals, detergents, or water. You can gently wipe the device's surface with a dry cloth.
- Do not squeeze the device with force or place heavy objects on the device, as this may damage the device.
- Do not throw, knock, or violently shake the device. Otherwise, damage may be caused to the internal components.
- Do not dry the device by putting it in heating equipment.
- Do not dismantle the device without the authorization from Puppy Robotics. If you have a problem, contact Puppy Robotics's customer service department.

puppy cube

