



Projector BP5000/BP5000PLUS

HP Projector Quick Start Guide

Technical Support: For more detailed usage instructions, please download the HP BP5000 / BP5000 Plus user manual at

GT Technology (Chongqing) Limited
The manufacturer under the
license of HP Inc.

Email: support@hp-projector.com
Web: www.hp-projector.com

Congratulations and thank you for choosing HP BP5000 / BP5000 Plus, part of the definitive premium cinema projection series. Be prepared for unparalleled audio-visual immersive experiences of up to 150 inches.



Package Contents:

HP BP5000 or HP BP5000 PLUS *1

<Accessories>

- Power Cord * 1
- Remote Control * 1
- AA battery * 2
- Quick Start Guide * 1
- HP Warranty Card * 1
- Product Notice * 1

Device Overview:



⚠ Notice:

- Do not place any articles around the air inlet hole to prevent cold air from entering and heat exchange cannot be carried out.
- Do not place any articles near the air outlet, which will cause the internal heat cannot be discharged and the internal heat will accumulate.

Specification parameter:

- | | |
|--------------------------------------|--|
| · USB : 5V,0.5A | · Environmental characteristics: ambient temperature 0-40°C, elevation below 5000m |
| · HDMI resolution: 4K | · AC-IN: 110-240V~,4A,50/60Hz |
| · Hardware specifications: 3G+32G | · LAN : 10/100Mbps |
| · Appearance of size: 595*340*140 MM | · Product size: 595*340*140mm |
| · Resolution: 4k UHD (3840*2160) | · Product net weight: 16kg |

HP BP5000/BP5000 PLUS Supported Input Sources:


- Embedded digital content platform (via wireless stick and/or RJ45 Ethernet port)
- Digital and Analog TV
- HDMI * 2 (including HDMI ARC)
- USB2.0*2


HP BP5000/BP5000 PLUS features an embedded powerful 30-watt stereo speaker set with deep bass, detailed mids and clear treble. However, the below audio outputs are also supported to suit your individual needs.

- S/PDIF * 1
- HDMI ARC *1
- 3.5mm earphone out
- Bluetooth (4.0)


How to use:

1. Place the projector onto a stable horizontal level surface (eg. table, TV stand) facing the desired vertical projection surface (eg. wall, projection screen). Plug the projector with the power cable into a working AC power socket, connect your external video and audio sources into the applicable input ports.
2. Before using the remote controller for the first time, insert the included AA batteries* 2 into the remote. Power on the projector and follow the on-screen instructions to pair the remote.
3. Enter the main page, as shown in the figure below:






5. When you are installing an external video device or audio system, the HP BP5000 / BP5000 Plus position is touched to cause the image Out of focus or abnormal change, please go to "Settings/Projection"



6. To ensure safe viewing and prevent eyesight damage, we recommend you enable Smart Eye Protection (Settings > Projection > Smart Eye Protection). During operation, DO NOT look directly straight-on at the projector lens.
7. You may also use BP5000/BP5000 Plus as a speaker (audio-only) without using the screen. (Settings > Switch off Display).
8. Voice input support is limited to mainland China.
9. If you want to watch photos and videos of mobile phones and Pads on the projector, you can use the wireless projection screen on the main interface
- To achieve screen sharing, you can refer to the connection instructions as shown in the figure to complete the screen sharing function.



1. 请将您的手机连接到网络"GATS".
2. 用浏览器访问"192.168.2.102:8000"或访问二维码下载安装客户端应用。
3. 打开EShare, 选择 "hp-projector-0242" 开始投屏。