




Quick Start Guide

Projector L1 / L1 Pro

Dear Customer,

Thank you for choosing Yaber!

Before using this projector, please read this Quick Start Guide carefully. Illustrations and function descriptions are provided for reference only. For complete instructions, please scan the QR code to access the full User Manual.

Please note: Due to ongoing product improvements and updates, the actual product may differ slightly from the descriptions or images shown. For the most accurate details, please refer to the physical product.

To ensure your utmost satisfaction, we want to reassure you that all our projectors undergo a rigorous 100% quality check and meticulous packaging before shipping.

Usually, many common problems can be solved with simple adjustments. If any further questions, please contact our support email: global@yaber.com. Please use the following subject line format: country code+order number+model, and a brief description of the problem (For example, **US+000-0000000-0000000+L1 Pro+No image**). Rest assured, our support team will promptly respond within 24 hours with an effective solution. Please excuse us if you don't receive a reply within 24 hours. It may be delayed due to a public holiday, or the email might have gone to your spam folder. Feel free to contact us again. Thank you.

Best Regards,
Yaber Team



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Scan the QR Code to Watch the Video Tutorial



PDF User Manual

Scan and download



Video Guideline

Scan to learn more



FAQ


Purchased Online:  global@yaber.com

 www.yaber.com

 [@yaberofficial](https://www.youtube.com/yaberofficial)

 [@yaber.projector](https://www.facebook.com/yaberprojector)


Package List




Yaber L1 / L1 Pro
Projector




Remote Control




Power Cable



HDMI Cable



Lens Cover







Cleaning Kit



Quick Start Guide


PROJECTOR OVERVIEW



Warm tips: We recommend cleaning the dust filter regularly.

Installation

The L1 Pro projector can be mounted on the ceiling using ceiling mount or placed on a stable desk, depending on the operating environment and requirements. Additionally, the L1 Pro projector can be installed using the following methods




Notes:

* Projection mode: Settings (⚙️) > Projector Settings > Projection direction > Front/ Rear/ Ceiling Front/ Ceiling Rear to select the corresponding projection mode, so the images can be projected correctly.

* The mounting hole is located on the back of the projector, not on the bracket.


Projection Distance and Size



*The recommended projection distance for the L1 Pro projector is **1.5-2.5 meters (4.9-8.2 ft)**. The image size depends on the distance and the projector's throw ratio, which is **1.19:1**. Additionally, the projector includes a **50% zoom-out** feature, allowing you to adjust the screen size without moving the projector.

*Actual projection size and distance may deviate slightly from laboratory data.

Remote Control



*Install 2 pieces of AAA batteries (not included) into the remote control before using it.

*The L1 Pro projector's HDMI port supports both HDMI CEC and ARC.

With **HDMI CEC**, you can use the L1 Pro's remote control to operate external devices connected via HDMI.

With **HDMI ARC**, you can connect a soundbar directly through HDMI without needing additional audio cables.

(Please ensure that HDMI CEC and ARC are enabled on your external devices.)

Manual Keystone Correction

If you need to further adjust the picture, you can select [Manual keystone correction] in the settings and drag the arrows on the remote control to adjust the picture.



Note: Please make sure the projector is not tilted more than 15° vertically or horizontally to ensure the image is clear.




Video Guideline Scan to learn more

Screen Mirroring






Note: The mobile phone cannot mirror streaming content, please prepare an additional TV stick.



iOS System Screen Mirroring

Attention: Ensure that your iOS device is connected to the same Wi-Fi network as your projector.

- 1) Connect the projector and your device to the same Wi-Fi network.
- 2) Access the [**Control Center**] on your iOS device -- Select the [**Screen Mirroring**] function -- Select and connect to the projector.
- 3) Succeed.






Android Device Screen Mirroring

Attention: Android devices may use various terms and methods to enable screen mirroring. Make sure to enable the WLAN function on your Android device.

- 1) Select [**Settings**] - Select [**System Settings**] - Select [**OS Cast**] or click the [] icon on the remote control. Select [**MediaCast**] - Click [**Click here to open MediaCast**] to enter the connection page and stay on this page
- 2) Access the [**Control Center**] on your Android device, select [**screen Mirroring/ smart View/ Cast**].
- 3) Select and connect the [**L1 Pro**]
- 4) When the [**invitation to connect**] appears on the projector screen, select [**Accept**]
- 5) Succeed.

Note: If you could not find [**Click here to open MediaCast**], please use your remote to scroll down to the bottom of the page.



Manual Keystone Correction



Notice: Since L1 Pro uses an open optical design, a small amount of dust may be inhaled during use. It is recommended to clean it regularly. Please scan the QR code to view the cleaning steps.



Video Guideline Scan
to learn more

Yaber
PROJECTOR